



What's in the box



Get to know Fire TV Cube



Light bar: The color indicates what Fire TV Cube is doing.

Volume buttons: Control the internal speaker of Fire TV Cube.


Action button: Multi-function button used to wake up Alexa.

IR port: Supports included IR extender. This is not an audio jack.

Micro-USB port: Used for external storage or for the Amazon Ethernet Adapter.


1. Where to place your device (before you plug it in...)

- Place Fire TV Cube 1 to 2 feet away from any speakers with the logo facing where you usually sit.
- This device acts like a remote control. It needs to hear you, and should be unobstructed and not in a closed cabinet.
- To control entertainment components that are inside a closed cabinet, use the optional IR extender cable.



2. Connect your Fire TV Cube

- Connect one end of the HDMI cable (not included) into the HDMI port on Fire TV Cube. Connect the other end into the HDMI port on your TV. Remember which HDMI port you plugged the device into (on your TV or AVR). You'll need that information later during setup.
- (Optional) To use an Ethernet cable (not included), connect the Amazon Ethernet Adapter as shown.
- Plug the included power cable into Fire TV Cube and then into a power outlet.



Things to Try

Control your TV and Sound Devices

Follow the on-screen instructions, or go to Settings on your Fire TV Cube to set up new entertainment devices.

Alexa, volume up.

Alexa, turn off the TV.

Alexa, turn off my receiver.

Alexa, switch to cable.

Alexa, tune to CNN.

Shows, Movies, Podcasts, Music, and Radio

Alexa, search for Iron Man 3.

Alexa, play NPR.

Alexa, play Radiolab.

News, Weather, and Traffic

Customize these features in the Alexa App.

Alexa, what's my flash briefing?


Alexa, what's the weather?

Alexa, how's my commute?


- Turn on your TV, and select the appropriate input.

- Set your TV volume to your typical listening level.

- (Optional) To use the IR extender cable, plug it into the IR port on the back of your Fire TV Cube as shown.




Place the IR extender cable on the same shelf as the devices you want to control (1). For devices on multiple shelves, place the IR extender cable on the lowest shelf (2).



3. Power up your Alexa Voice Remote

- Open the back of the remote and insert the included batteries.
- After pairing your Alexa Voice Remote, follow the on-screen instructions to control the power and volume of your TV.



If your remote isn't discovered, press and hold the Home button until the LED starts to rapidly flash amber.

Tips and troubleshooting

Wi-Fi network

- Using the included remote control, go to the Settings menu in Fire TV Cube, and select your network from the list displayed. If your network is hidden, enter your network name.
- If you see a lock icon, your Wi-Fi network requires a password, so make sure you have it available. This password is not your Amazon account password.
- For best performance, use the 5GHz band on your wireless router if available. Do not place your router in a cabinet as it may impact Wi-Fi signal strength.

Wired network

If you're having trouble with your Ethernet connection, verify that the Ethernet cable and adapter are properly connected, then restart your Fire TV Cube.

For more troubleshooting and information, go to www.amazon.com/devicesupport.